

# **RIGOL**

## **Service Guide**

### **DS1000E, DS1000D Series Digital Oscilloscopes**

DS1102E, DS1052E, DS1102D, DS1052D

**May 2009**  
**RIGOL Technologies, Inc.**



## **Copyright**

© 2009 RIGOL Technologies, Inc. All Rights Reserved.

## **Trademark Information**

**RIGOL** is registered trademark of **RIGOL** Technologies, Inc.

## **Notices**

**RIGOL** products are protected by patent law in and outside of P.R.C..

**RIGOL** Technologies, Inc. reserves the right to modify or change parts of or all the specifications and pricing policies at company's sole decision.

Information in this publication replaces all previously corresponding material.

**RIGOL** shall not be liable for losses caused by either incidental or consequential in connection with the furnishing, use or performance of this manual as well as any information contained.

Any part of this document is forbidden to copy or photocopy or rearrange without prior written approval of **RIGOL**.

## Safety Notices

Review the following safety precautions carefully before operating the instrument to avoid any personal injuries or damages to the instrument and any product connected to it. To prevent potential hazards, do use the instrument specified by this user's guide only.

### **The instrument should be serviced by qualified personnel only.**

To avoid instrument damage or personnel injury caused by misoperation, the instrument should be serviced by qualified personnel only.

### **Use Proper Power Cord.**

Use the power cord designed for the instrument and authorized in your country only.

### **Connect and Disconnect Accessories.**

Do not connect or disconnect probes or test leads while they are connected to a voltage source.

### **Ground The Instrument.**

The oscilloscope is grounded through the grounding conductor of the power cord. To avoid electric shock the instrument grounding conductor(s) must be grounded properly. Before making connections to the input or output terminals of the instrument.

### **Connect The Probe.**

The probes' ground terminals are at the same voltage level of the instrument ground. Do not connect the ground terminals to a high voltage.

### **Observe All Terminal Ratings.**

To avoid fire or shock hazard, observe all ratings and marks on the instrument. Follow the user's guide for further ratings information before making connections to the instrument.

### **Do Not Operate Without Covers.**

Do not operate the instrument with covers or panels removed.

### **Use Proper Fuse.**

Use the fuse of the type, voltage and current ratings as specified for the instrument.

### **Avoid Circuit or Wire Exposure.**

Do not touch exposed connections and components when power is on.

### **Do Not Operate With Suspected Failures.**

If suspected damage occurs with the instrument, have it inspected by qualified service personnel before further operations.

**Keep Well Ventilation.**

Inadequately ventilated will cause the temperature rises or damages to the device. Please keep well ventilation and inspect the intake and fan regularly.

**Do not Operate in Wet/Damp Conditions.**

In order to avoid short circuit to the interior of the device or electric shock, please do not operate in a humid environment.

**Do not Operate in an Explosive atmosphere.**

In order to avoid damages to the device or personal injury, please operate far away from an explosive atmosphere.

**Keep Product Surfaces Clean and Dry.**

In order to prevent the performance of the device from influencing by dust or water in air, please keep the surface of device clean and dry.

**The disturbance test of all the models meet the limit values of A in the standard of EN 61326: 1997+A1+A2+A3, but can't meet the limit values of B.**

**Measurement Category**

The DS1000E, DS1000D series Digital Oscilloscope is intended to be used for measurements in Measurement Category I.

**Measurement Category Definitions**

Measurement Category I is for measurements performed on circuits not directly connected to MAINS. Examples are measurements on circuits not derived from MAINS, and specially protected (internal) MAINS derived circuits. In the latter case, transient stresses are variable; for that reason, the transient withstand capability of the equipment is made known to the user.

**WARNING**

IEC Measurement Category I, The input terminals may be connected to circuit terminal in IEC Category I installations for voltages up to 300 VAC. To avoid the danger of electric shock, do not connect the inputs to circuit's voltages above 300 VAC. Transient overvoltage is also present on circuits that are isolated from mains. The DS1000E, DS1000D series Digital Oscilloscopes is designed to safely withstand occasional transient overvoltage up to 1000Vpk. Do not use this equipment to measure circuits where transient overvoltage could exceed this level.

## Safety Terms and Symbols

**Terms in this Guide.** These terms may appear in this manual:



---

**WARNING**

Warning statements indicate the conditions or practices that could result in injury or loss of life.

---



---

**CAUTION**

Caution statements indicate the conditions or practices that could result in damage to this product or other property.

---

**Terms on the Product.** These terms may appear on the product:

**DANGER** indicates an injury or hazard that may immediately happen.

**WARNING** indicates a potential injury or hazard that may happen.

**CAUTION** indicates that a potential damage to the instrument or other property might occur.

**Symbols on the Product.** These symbols may appear on the product:



**Hazardous Voltage**



**Refer to Instructions**



**Protective Earth Terminal**



**Chassis Ground**



**Test Ground**

# Document Overview

## **Chapter 1 Specifications**

List the specifications and general specifications of DS1000E, DS1000D series.

## **Chapter 2 Prepare for Use**

Introduce the preparatory work should be done before using the oscilloscope.

## **Chapter 3 Performance Test**

Introduce how to execute the performance test to understand current performance status of the oscilloscope.

## **Chapter 4 Calibration**

Introduce how to calibrate the oscilloscope.

## **Chapter 5 Disassembly and Assembly**

Introduce how to disassemble and assemble the oscilloscope to understand its structure.

## **Chapter 6 Troubleshooting**

List the troubles may appear during measuring and the corresponding solutions.

## **Chapter 7 Replaceable Parts**

List the replaceable parts for user's repair or exchange.

## **Chapter 8 Service & Support**

Provide the service and support information.

# Contents

Safety Notices .....	II
Safety Terms and Symbols.....	IV
Document Overview.....	V
Contents .....	VI
Figures.....	VIII
Tables .....	IX
<b>Chapter 1 Specifications .....</b>	<b>1-1</b>
Specifications .....	1-2
General Specifications .....	1-5
<b>Chapter 2 Prepare for Use .....</b>	<b>2-1</b>
General Inspection.....	2-2
Power-On Inspection.....	2-3
Connect the Probe .....	2-4
Probe Compensation .....	2-5
Digital Probe (Only for DS1000D Series) .....	2-7
Display a Waveform Automatically.....	2-9
<b>Chapter 3 Performance Test .....</b>	<b>3-1</b>
Interfaces Test.....	3-2
USB Host Interface Test.....	3-2
USB Device Interface Test.....	3-4
RS-232 Interface Test.....	3-6
P/F Interface Test.....	3-8
Logic Analyzer Interface Test (Only for DS1000D Series) .....	3-9
Specifications Test .....	3-11
<b>Chapter 4 Calibration.....</b>	<b>4-1</b>
<b>Chapter 5 Disassembly and Assembly .....</b>	<b>5-1</b>
Notices .....	5-2
Structure Chart.....	5-3
Disassemble and Assemble the Cover .....	5-4
Disassemble and Assemble the Upper and Rear Covers .....	5-5
Disassemble and Assemble the Power Board and the Fan .....	5-6
Disassemble and Assemble the Panel .....	5-8
Disassemble and Assemble LCD and the Keyboard .....	5-9
Disassemble and Assemble the Mainboard .....	5-10
<b>Chapter 6 Troubleshooting .....</b>	<b>6-1</b>
<b>Chapter 7 Replaceable Parts.....</b>	<b>7-1</b>
<b>Chapter 8 Service &amp; Support.....</b>	<b>8-1</b>

Warranty .....8-2  
Care and Cleaning .....8-3  
Contact Us.....8-4  
**Index..... 1**

## Figures

Figure 2-1 Connect the power cord .....	2-3
Figure 2-2 Power-on inspection .....	2-3
Figure 2-3 Connect probe to oscilloscope .....	2-4
Figure 2-4 Connect probe to circuit .....	2-4
Figure 2-5 Set the probe attenuation quotient and switch .....	2-5
Figure 2-6 Connect the probe compensator .....	2-5
Figure 2-7 Waveform compensation .....	2-6
Figure 2-8 Connect the digital probes to oscilloscope .....	2-7
Figure 2-9 Test clip of digital probe .....	2-7
Figure 2-10 Attach the clip to testing point .....	2-8
Figure 2-11 Connecting to the ground .....	2-8
Figure 3-1 Connect the U disk .....	3-2
Figure 3-2 Successful prompt of USB interface connection .....	3-2
Figure 3-3 USB Device interface connection .....	3-4
Figure 3-4 Select USB interface .....	3-4
Figure 3-5 Fail prompt of USB interface connection .....	3-5
Figure 3-6 RS-232 interface connection .....	3-6
Figure 3-7 Select RS-232 interface .....	3-6
Figure 3-8 RS-232 interface setting .....	3-7
Figure 3-9 Fail prompt of RS-232 interface connection .....	3-7
Figure 3-10 P/F interface connection .....	3-8
Figure 3-11 DS1000D LA interface connection .....	3-9
Figure 3-12 Setting interface .....	3-10
Figure 3-13 Edge trigger of digital channel .....	3-10
Figure 3-14 Connect the testing device .....	3-11
Figure 4-1 Self-Calibration interface .....	4-1
Figure 4-2 Finish Self-Calibration .....	4-1
Figure 5-1 Structure chart .....	5-3
Figure 5-2 Disassemble and assemble the cover .....	5-4
Figure 5-3 Disassemble and assemble the upper and rear covers .....	5-5
Figure 5-4 Disassemble and assemble the power board and the fan .....	5-6
Figure 5-5 Disassemble and assemble the panel .....	5-8
Figure 5-6 Disassemble and assemble LCD and the keyboard .....	5-9
Figure 5-7 Disassemble and assemble the mainboard .....	5-10
Figure 7-1 DS1000E, DS1000D Exploded View .....	7-1

---

## Tables

Table 2-1 The auto items.....	2-9
Table 3-1 Pass/Fail setting items.....	3-8
Table 3-2 Testing specifications and the ranges.....	3-11
Table 7-1 Replaceable parts list.....	7-1



# Chapter 1 Specifications

All specifications apply to DS1000E, DS1000D series Oscilloscopes unless noted otherwise. To meet these specifications, two conditions must first be met:

- The instrument must have been operating continuously for thirty minutes within the specified operating temperature.
- Do perform the "Self Cal" operation, accessible through the Utility menu, if the operating temperature changes by more than 5°C.

**NOTE:** All specifications are guaranteed unless noted "typical".

## Specifications

<b>Acquisition</b>				
Sampling Modes	Real-Time		Equivalent	
Sampling Rate	1GSa/s, 200MSa/s <sup>[1]</sup>		DS1102X	DS1052X
			25GSa/s	10GSa/s
Averages	N time acquisitions, all channels simultaneously, N is selectable from 2, 4, 8, 16, 32, 64, 128 and 256.			
<b>Inputs</b>				
Input Coupling	DC, AC, GND			
Input Impedance	1M $\Omega$ ±2% 18pF±3pF			
Probe Attenuation Factors	1X, 5X, 10X, 50X, 100X, 500X, 1000X			
Maximum Input Voltage	400V (DC+AC Peak, 1M $\Omega$ input impedance)			
	40V (DC+AC Peak) <sup>[1]</sup>			
Time delay between channel (typical)	500ps			
<b>Horizontal</b>				
Sample Rate Range	Real-Time: 13.65Sa/s-1GSa/s Equivalent: 13.65Sa/s-25GSa/s			
Waveform interpolation	Sin(x)/x			
Record Length	Channel Mode	Sample rate	Record Length (normal)	Record Length (long record)
	Single channel	1GSa/s	16kpts	N.A.
	Single channel	500MSa/s Or lower	16kpts	1Mpts
	Double channel	500MSa/s Or lower	8kpts	N.A.
Double channel	250MSa/s Or lower	8kpts	512kpts	
Scan speed Range (Sec/div)	2ns/div~50s/div, DS1102X 5ns/div~50s/div, DS1052X 1-2-5 Sequence			
Sample Rate and Delay Time Accuracy	±50ppm (over any 1ms time interval)			
Delta Time Measurement Accuracy (Full Bandwidth)	Single-shot: ±(1 sample interval + 50ppm × reading + 0.6 ns) >16 averages: ±(1sample interval + 50ppm × reading + 0.4 ns)			
<b>Vertical</b>				

A/D converter	8-bit resolution, each channel samples simultaneously <sup>[2]</sup>	
Volts/div Range	2mV/div~10V/div at input BNC	
Maximum Input	Analog channel maximum input voltage CAT I 300Vrms, 1000Vpk; instantaneous voltage 1000Vpk CAT II 100Vrms, 1000Vpk RP2200 10:1: CAT II 300Vrms RP3200 10:1: CAT II 300Vrms RP3300 10:1: CAT II 300Vrms	
Offset Range	±40V(250mV/div~10V/div), ±2V(2mV/div~245mV/div)	
Analog Bandwidth	100MHz (DS1102D, DS1102E) 50MHz (DS1052D, DS1052E)	
Single-shot Bandwidth	100MHz (DS1102D, DS1102E) 50MHz (DS1052D, DS1052E)	
Selectable Analog Bandwidth Limit (typical)	20MHz	
Lower Frequency Limit (AC -3dB)	≤5Hz (at input BNC)	
Rise Time at BNC, typical	<3.5ns, <7ns, On (100MHz, 50MHz) respectively	
Dynamic range	±5div	
DC Gain Accuracy	2mV/div-5mV/div: ±4% (Normal or Average acquisition mode) 10mV/div-10V/div: ±3% (Normal or Average acquisition mode)	
DC Measurement Accuracy, Average Acquisition Mode	Average of ≥16 Waveforms with vertical position at zero: ±(DC Gain Accuracy×reading+0.1div+1mV) Average of ≥16 Waveforms with vertical position not at zero: ±[DC Gain Accuracy×(reading+vertical position)+(1% of vertical position) + 0.2div] Add 2mV for settings from 2mV/div to 245 mV/div Add 50mV for settings from >250mV/div to 10V/div	
Delta Volts Measurement Accuracy (Average Acquisition Mode)	Delta Volts between any two averages of 16 waveforms acquired under same setup and ambient conditions: ±(DC Gain Accuracy×reading + 0.05 div)	

### Trigger

Trigger Sensitivity	0.1div~1.0div (adjustable)	
Trigger Level Range	Internal	±6 divisions from center of screen
	EXT	±1.2V
Trigger Level Accuracy (typical) applicable for the signal of rising and falling time ≥20ns	Internal	±(0.3div × V/div)(±4 divisions from center of screen)
	EXT	±(6% of setting + 200 mV)

Trigger Offset	Normal mode: pre-trigger (storage depth/ 2*sampling rate), delayed trigger 1s
	Slow Scan mode: pre-trigger 6div, delayed trigger 6div
Trigger Holdoff range	500ns~1.5s
Set Level to 50% (Typical)	Input signal frequency $\geq 50\text{Hz}$

**Edge Trigger**

Edge trigger slope	Rising, Falling, Rising + Falling
--------------------	-----------------------------------

**Pulse Trigger**

Trigger condition	( $>$ , $<$ , $=$ ) Positive pulse, ( $>$ , $<$ , $=$ ) negative pulse
Pulse Width range	20ns ~10s

**Video Trigger**

Video standard & line frequency	Support standard NTSC, PAL and SECAM broadcast systems. Line number range: 1~525 (NTSC) and 1~625 (PAL/SECAM)
---------------------------------	--

**Slope Trigger**

Trigger condition	( $>$ , $<$ , $=$ ) Positive slope, ( $>$ , $<$ , $=$ ) negative slope
Time setting	20ns~10s

**Alternate Trigger**

Trigger on CH1	Edge, Pulse, Video, Slope
Trigger on CH2	Edge, Pulse, Video, Slope

**Pattern Trigger**<sup>[1]</sup>

Trigger mode	D0~D15 select H, L, X, $\mathcal{F}$ , $\mathcal{T}$
--------------	--

**Duration Trigger**<sup>[1]</sup>

Trigger Type	D0~D15 select H, L, X
Qualifier	$>$ , $<$ , $=$
Time setup	20ns~10s

**Measurements**

Cursor	Manual	Voltage difference between cursors ( $\Delta V$ ) Time difference between cursors ( $\Delta T$ ) Reciprocal of $\Delta T$ in Hertz ( $1/\Delta T$ )
	Track	Voltage value for Y-axis waveform Time value for X-axis waveform
	Auto	Cursors are visible for Automatic Measurement
Auto Measure	Vpp, Vamp, Vmax, Vmin, Vtop, Vbase, Vavg, Vrms, Overshoot, Preshoot, Freq, Period, Rise Time, Fall Time, +Width, -Width, +Duty, -Duty, Delay1 $\rightarrow$ 2 $\mathcal{F}$ , Delay1 $\rightarrow$ 2 $\mathcal{T}$	

**Remarks:**

[1] For DS1000D series;

[2] When sampling is 1GSa/s, only single channel can be used.

## General Specifications

<b>Display</b>		
Display Type	5.7 in. (145 mm) diagonal TFT Liquid Crystal Display	
Display Resolution	320 horizontal ×RGB×234 vertical pixels	
Display Color	64k color	
Display Contrast (typical)	150:1	
Backlight Brightness(typical)	300 nit	
<b>Probe Compensator Output</b>		
Output Voltage(typical)	Approximately 3Vpp (peak to peak value)	
Frequency(typical)	1kHz	
<b>Power</b>		
Supply Voltage	100 ~ 240 VAC <sub>RMS</sub> , 45~440Hz, CAT II	
Power Consumption	Less than 50W	
Fuse	2A, T rating, 250 V	
<b>Environmental</b>		
Ambient Temperature	Operating 10°C ~ 40°C	
	Non-operating -20°C ~ +60°C	
Cooling Method	Fan force air flow	
Humidity	+35°C or below: ≤90% relative humidity	
	+35°C ~ +40°C: ≤60% relative humidity	
Altitude	Operating 3,000 m or below	
	Non-operating 15,000 m or below	
<b>Mechanical</b>		
Size	Width	303mm
	Height	154mm
	Depth	133 mm
Heavy	Without package	2.3 kg
	Packaged	3.5 kg
<b>IP Protection</b>		
IP2X		
<b>Calibration Interval</b>		
The recommended calibration interval is one year		



## Chapter 2 Prepare for Use

This chapter contains the following topics:

- General Inspection
- Power-On Inspection
- Connect the Probe
- Probe Compensation
- Digital Probe (Only for DS1000D Series)
- Display a Waveform Automatically

## General Inspection

When you get a new DS1000E, DS1000D series oscilloscope, please inspect the instrument according to the following steps:

### 1. Inspect the shipping container for damage.

Keep a damaged shipping container and cushioning material until the contents of the shipment have been checked for completeness and the instrument has been checked mechanically and electrically.

### 2. Inspect the instrument.

In case there is any mechanical damage or defect, or the instrument does not operate properly or fails performance tests, please notify the **RIGOL** Sales Representative.

If the shipping container is damaged, or the cushioning materials show signs of stress, please notify the carrier as well as the **RIGOL** sales office. Keep the shipping materials for the carrier's inspection. **RIGOL** offices will arrange for repair or replacement at **RIGOL**'s option without waiting for claim settlement.

### 3. Check the accessories.

Accessories supplied with the instrument are listed below. If the contents are incomplete or damaged, please notify the **RIGOL** Sales Representative.

#### Standard Accessories:

- Probex2 (1.5m), (1:1 or 10:1 adjustable) Passive Probes  
The passive probes have a 6MHz bandwidth with a rating of 150V CAT II when the switch is in the 1X position, and a Full oscilloscope bandwidth with a rating of 300 V CAT II when the switch is in the 10X position.
- A Power Cord that fits the standard of destination country
- An USB Cable
- A Logic Cable (only for DS1000D series)
- An active logic head (only for DS1000D series)
- 20 Logic Testing Nips (only for DS1000D series)
- 20 Logic Testing Leads (only for DS1000D series)
- A CD-ROM (including "User's Guide" and Application Software)
- A Quick Guide

## Power-On Inspection

Generally, normal operating voltage and frequency for DS1000E, DS1000D series digital oscilloscope are 100-240V<sub>RMS</sub> and 45-440Hz respectively. Please connect one terminal of the power cord to the socket in left side of the oscilloscope and the other to the AC power source.




Figure 2-1 Connect the power cord

Press the power button on top of the oscilloscope, some keys on the front panel will light for about 2 seconds until the normal display appears. And then you can operate the oscilloscope.



### WARNING

To avoid the electric shock, make sure the oscilloscope is under good grounding before connecting AC power.

After power-on, the oscilloscope performs all the self-testing automatically. Then, press **Storage** and select **Storage** to recall the **Factory** settings after passing test (the screen will appear).




Figure 2-2 Power-on inspection

## Connect the Probe

DS1000E series is a type of digital oscilloscope with dual channel inputs and one external trigger input. While, DS1000D series is a type with dual channel input, one external trigger input and sixteen channel digital inputs.

Please take the following steps to connect the probe:

1. Attach BNC connector of the probe to the channel input or external trigger interfaces, insert it vertically until it latches into places. Then circumvolve the BNC connector clockwise to get a firm connection.




Figure 2-3 Connect probe to oscilloscope

2. Connect the other end of probe to circuit under test.




Figure 2-4 Connect probe to circuit

3. Disconnect the circuit after testing, and then circumvolve the BNC connector of probe anticlockwise, and pull it out of the interface vertically.



### WARNING

When use 10:1 attenuation probe, don't input a signal with higher than maximum input voltage.

## Probe Compensation

You are suggested to compensate probe before first using so as to match its characteristics with oscilloscope. Measurement error may be generated without compensation or because of deviation compensation. To compensate the probe, follow the steps below.

1. Set both the attenuation switch of the probe and the probe scale in the menu to 10X.




Figure 2-5 Set the probe attenuation quotient and switch

2. Connect the probe to CH1. And attach both the probe tip and ground lead to the connector of probe compensator.




Figure 2-6 Connect the probe compensator

3. Open CH1 and press **AUTO** button after a few seconds, a square wave will be displayed (1 kHz, approximately 3 V peak- to- peak). Check if the compensation is

correct in accordance with the shape of waveform.




Figure 2-7 Waveform compensation

4. If necessary, use a non-metallic screwdriver to adjust the variable capacitor of the probe until a "Correct Compensation" wave displayed on the screen.
5. Continue in the same way to check CH2.



---

**WARNING**

To avoid electric shock while using the probe, be sure the perfection of the insulated cable, and do not touch the metallic portions of the probe head while it is connected with a high-voltage power supply.

---

## Digital Probe (Only for DS1000D Series)

DS1000D series provide sixteen digital channels. Take the steps below to connect instrument and test points by digital probes:

1. Switch off power supply of the device under test if necessary to avoid short circuit. Since no voltage is applied to the leads at this step, you may keep the oscilloscope on.
2. Connect one terminal of the flat cable FC1868 to the Logic Analyzer Input; connect the other end to Logic Head LH1116. An identifier is located on each end of the flat cable; it can only be connected in one way. It is unnecessary to switch off power supply of your oscilloscope when connecting the cable.




Figure 2-8 Connect the digital probes to oscilloscope



### CAUTION

Use only FC1868, LH1116, TC1100 and LC1150 made by **RIGOL** for specified DS1000D series.

3. Connect a test clip to one lead wire; make sure it's connection good.



Figure 2-9 Test clip of digital probe

4. Test your device with the clip.




Figure 2-10 Attach the clip to testing point

- 5. Connect the test clip to the ground.




Figure 2-11 Connect to the ground

## Display a Waveform Automatically

DS1000E, DS1000D series digital oscilloscopes have an automatic feature to display the input signal best-fit. The oscilloscope enables to automatically set up VERTICAL, HORIZONTAL and TRIGGER parameters for the input signal under display. The input signal should be 50Hz or higher of frequency and the duty cycle of which should greater than 1%.

### 1. Operation steps

- Connect a signal to input channel.
- Press **AUTO** and adjust parameters manually to get the best display if necessary.

### 2. Auto settings

Table 2-1 The auto items

Functions	Settings
Display format	Y-T
Acquire mode	Normal
Vertical coupling	Adjust to AC or DC according to the signal.
Vertical "V/div"	Adjust to right position
Volts/Div	Coarse
Bandwidth limit	Full
Signal Invert	OFF
Horizontal position	Center
Horizontal "S/div"	Adjust to right position
Trigger type	Edge
Trigger source	Find the channel with input signal automatically.
Trigger coupling	DC
Trigger voltage	Midpoint setting
Trigger mode	Auto
 POSITION knob	Trigger offset



## Chapter 3 Performance Test

This chapter contains the following topics:

- Interfaces Test
  - USB Host Interface Test
  - USB Device Interface Test
  - RS-232 Interface Test
  - P/F Interface Test
  - Logic Analyzer Interface Test (Only for DS1000D Series)
- Specifications Test

## Interfaces Test

### USB Host Interface Test

**Purpose:**

Test if the **USB Host** interface works normally through U disc.

**Tools:**

- A set of DS1000E, DS1000D series digital oscilloscope
- An U disk

**Steps:**

1. Insert the U disk into the USB Host interface on the front panel of the oscilloscope.




Figure 3-1 Connect the U disk

2. Wait until a prompt "USB device install success" appeared on the screen, which indicates the USB Host interface works normally, otherwise, you need to check or repair this interface.



Figure 3-2 Successful prompt of USB interface connection

3. If an update program about the oscilloscope available in the U disc is detected, a prompt will appear to ask you whether to update or not; if select OK, the corresponding update process will be shown on the screen.
4. Press **Storage** → **External** to copy or delete the information in U disc.
5. Remove the U disc and a corresponding prompt "USB device removed" will appear.

## USB Device Interface Test

### Purpose:

Test if the **USB Device** interface works normally through Ultrascope for DS1000E, DS1000D series.

### Tools:

- A set of DS1000E, DS1000D series digital oscilloscope
- A PC with USB interface
- A standard USB cable (Type AB)
- Ultrascope for DS1000E, DS1000D series

### Steps:

1. Install the Ultrascope for DS1000E, DS1000D series software on the PC.
2. Connect the oscilloscope with PC using an USB cable, and install the driver program step by step following the prompt.




Figure 3-3 USB Device interface connection

3. Run Ultrascope for DS1000E, DS1000D series, then click **Tools**→**Options** and select **USB** as the current **IO**.




Figure 3-4 Select USB interface

4. Click **Tools** → **Connect to Oscilloscope**; If successful, the corresponding indicator at the upper right corner of the software will be changed from red to blue; if failed, a prompting message will be appeared as below.



Figure 3-5 Fail to connection

**Hint**

For the newest version of this software please go to [www.rigolna.com](http://www.rigolna.com) download.

## RS-232 Interface Test

### Purpose:

Test if **RS-232** interface works normally through Ultrascope for DS1000E, DS1000D series.

### Tools:

- A set of DS1000E, DS1000D series digital oscilloscope
- A PC with RS-232 interface
- A standard RS-232 cable
- Ultrascope for DS1000E, DS1000D series

### Steps:

1. Install the Ultrascope for DS1000E, DS1000D series software on the PC.
2. Connect the oscilloscope with PC using an RS-232 cable.




Figure 3-6 RS-232 interface connection

3. Run Ultrascope for DS1000E, DS1000D Series, then click **Tools**→**Options** and select **RS-232** as the current **IO**.




Figure 3-7 Select RS-232 interface

4. Click **Communication Setting** and setup the communication interface under using and the baud rate.




Figure 3-8 RS-232 interface setting

5. Press **Utility** → **I/O Setting** and set the baud rate as the same value in Ultrascope.
6. Click **Tools** → **Connect to Oscilloscope**; If successful, the corresponding reminder light at the upper right corner of the software will be changed from red to blue; otherwise, a prompting message will be appeared as below.



Figure 3-9 Fail prompt of RS-232 interface connection

## P/F Interface Test

### Purpose:

Test if **P/F** interface work normally through RS5101 module.

### Tools:

- A set of DS1000E, DS1000D series digital oscilloscope
- A BNC cable
- A RD5101 module

### Steps:

1. Power on the oscilloscope and RD5101 respectively.
2. Connect P/F interface on DS1000E, DS1000D with [Pass/Fail out] interface on RD5101 by BNC cable.




Figure 3-10 P/F interface connection

3. Turn on the oscilloscope, press **Storage** → **Storage** → **Factory** to recall the factory settings.
4. Press **Utility** → **Pass/fail** to enter the setting interface of Pass/Fail, see the table below

Table 3-1 Pass/Fail setting items

Items	Setting
Enable Test	ON
Source	CH1
Msg display	ON
Output	Fail
Stop on Output	OFF

5. After setting, press **Operate** to start Pass/Fail test.
6. Observe the reminder light of PASS/FAIL INDICATO of RRD5101; if the reminder light twinkles at a frequency, which indicates that the interface works normally, if no response to the lighter, errors might happened to the interface.

## Logic Analyzer Interface Test (Only for DS1000D Series)

### Purpose:

Test if the Logic Analyzer (hereinafter referred to as LA) interface works normally through the logic signal output module (DG-POD-A) of DG3000.

### Tools:

- A set of DS1000D series digital oscilloscope
- A set of DG3000 Function/ Arbitrary waveform Generator
- An active logic head
- Two logic cables
- 17 logic testing leads
- A DG-POD-A module

### Steps:

1. Connect LA interface on DS1000D with the active logic head by logic cable.
2. Connect "DIGITAL OUTPUT" interface on the rear panel of DG3000 with DG-POD-A module by logic cable.
3. Connect the active logic head with DG-POD-A module by logic testing leads, so as to realize DS1000D and DG3000 connection.




Figure 3-11 DS1000D LA interface connection

4. Power on DS1000D and DG3000 respectively.
5. Turn on DG3000 and press **Utility** → **Output Setup** → **Digit-Modu** → **Power on** to enable the digital module power on.
6. Press **Arb** → **Edit Digital W**, select **Protocol** → **PO**, **Code Pat** → **32PRBS** and adjust **Output Length** as 16 Byte as follows, then press **Arb** button to output digital signal.




Figure 3-12 Setting interface

7. Press **LA** button on the oscilloscope, select **D7-D0** and **D15-D8** to open all the logic channels.
8. Select **EDGE** mode under the trigger menu and select any one source among Do to D15, if obtain the stable interface as follows, the LA module will be proved works normally.




Figure 3-13 Edge trigger of digital channel

## Specifications Test

### Purpose:

Test if all the specifications are in the specified range.

### Requirement:

Verify whether the oscilloscope is qualified through FLUKE calibration instrument and relative softwares.

### Tools:

- A set of DS1000E, DS1000D series oscilloscope
- A set of FLUKE 9500B calibration instrument for oscilloscope and accessories to it
- Auxiliary testing softwares
- A computer with GPIB and USB interfaces
- A GPIB cable
- A standard USB cable (Type AB)
- Three BNC terminals with 50Ω of resistance

### Steps:

1. Connect the FLUKE oscilloscope with PC using a GPIB cable.




Figure 3-14 Connect the testing device

2. Connect the oscilloscope with PC using an USB cable.
3. Use the testing software to test the specifications listed in the table below. Check if all the specifications are in the specified range.

Table 3-2 Testing specifications and the ranges

Testing item	Returned value	Errors
Noise	V <sub>pp</sub> : CH1, CH2	0.0~0.65div
Input impedance	Input impedance: CH1:100mV 500mV CH2:100mV 500mV	1MΩ±2%, in parallel with 15pF±3pF 1MΩ±2%, in parallel with 15pF±3pF

		1M $\Omega$ $\pm$ 2%, in parallel with 15pF $\pm$ 3pF 1M $\Omega$ $\pm$ 2%, in parallel with 15pF $\pm$ 3pF
Voltage accuracy	Relative error between the average and the actual: CH1, CH2 2mV, 5mV scale >5mV scale	$\pm$ 4% $\pm$ 3%
DC linearity	DC voltage error array: CH1, CH2 200mV scale 5V scale	-2.60~2.60(mV) -2.60~2.60(mV)
DC offset	Relative error of the voltage: CH1, CH2, 5V scale	0~6%
Horizontal time Accuracy	delta-t error	-5.00e-9~5.00e-9(s)
Trigger sensitivity	Trigger sensitivity error: 10MHz Full bandwidth	0.1~1.0div 0.1~1.5div
Timebase linearity	Period error	0.0~5.0e-10(s)
Channel delay	Delay: CH1, CH2	500ps
Trigger delay	Delay: CH1, CH2	500ps

## Chapter 4 Calibration

The oscilloscope can achieve the optimum state fleetly by performing the calibration program and get accurate measurement. You can execute the calibration at any time. But when the operating temperature changes up to or more than 5°C, you must perform this programme.

### NOTE:

The oscilloscope must have been working or warm-up **at least 30-minutes** before running self-calibration to get best accuracy.

### Steps:

1. Disconnect any probes or cables from all channel inputs, otherwise failure or damage to the oscilloscope may occur.
2. Press **Utility** → **Self-Cal**, enter the Self-Calibration interface.




Figure 4-1 Self-Calibration interface

3. Press **RUN/STOP** to start the Self-Calibration, the oscilloscope will calibrate the vertical system (CH1, CH2 and Ext), horizontal system and the trigger system automatically to guarantee the specifications in different environment.
4. The screen will give a message of "Calibration finished" after finish the calibration and you can press **RUN/STOP** to exit.



Figure 4-2 Finish Self-Calibration

Generally speaking, the Self-Calibration will take about 5-6 minutes, if the calibration does not pass after this time, or the progress bar stop at one of the calibration item, there may be a trouble to the instrument. To resolve the trouble, restart the instrument and perform the Self-Calibration again, if the problem still remains, contact **RIGOL** for help.

## Chapter 5 Disassembly and Assembly

This chapter includes the following topics:

- Notices
- Structure Chart
- Disassemble and Assemble the Cover
- Disassemble and Assemble the Upper and Rear Cover
- Disassemble and Assemble the Power Board and the Fan
- Disassemble and Assemble the Panel
- Disassemble and Assemble LCD and the Keyboard
- Disassemble and Assemble the Mainboard

## Notices

### Notices:

- Don't disassemble the product except the work needed.
- Disassemble only can be done by qualified person.
- Cut the power before disassembling.
- Take ESD glove under disassembling.
- Use proper tools and follow the disassembly sequence.
- Prevent metallic parts from transfiguration and avoid being scratched when disassembling.

### Required tools:

- TORX drivers (T6, T10, T20)
- BNC sleeve



---

**WARNING**

Before disassembling, please make sure the power has been cut off. The operator should be trained or had related qualification.

---

# Structure Chart




Figure 5-1 Structure chart

## Disassemble and Assemble the Cover




Figure 5-2 Disassemble and assemble the cover

### Parts Explanations:

- ① Bolts on the bottom of the cover (M3\*8 Pan head Torx recess Drilling tapping screws): 2
- ② Bolts at the groove of the handle (M3\*8 Pan head Torx recess machine screws): 2

### Disassemble steps:

1. Backout both the two bolts ① and ② using a TORX driver (T10);
2. Jiggle the power button and pull the cap out from it;
3. Remove the cover at the power socket forcibly.

### Assemble steps:

About assembly, please operate as reverse orders, the same below.

## Disassemble and Assemble the Upper and Rear Covers




Figure 5-3 Disassemble and assemble the upper and rear covers

### Parts Explanations:

- ③ Bolts at the interface of RS-232 (DB9 interface bolts): 2
- ④ Bolts at the upper cover (M3\*6 Pan head Torx recess composite machine screws): 2

### Disassemble steps:

1. Backout the two bolts ③ and remove the rear cover;
2. Backout the two bolts ④ using a TORX driver (T10); Then, remove the upper cover.

## Disassemble and Assemble the Power Board and the Fan




Figure 5-4 Disassemble and assemble the power board and the fan

### Parts Explanations:

- ⑤ Small bolts for fixing the power board (M3\*6 Pan head Torx recess composite machine screws): 3
- ⑥ Big bolts for fixing the power board (M4\*8 Pan head Torx recess machine screws): 1
- ⑦ Bolts (M3\*8 Pan head Torx recess Drilling tapping screws) and nuts (M3 hexagon nut with locking plate) for linking up the power board and shell: 2 pairs
- ⑧ Bolts for fixing the fan (M5\*8 Pan head Torx recess machine screws): 4

### Disassemble steps:

1. Pull out the power line 12pin from the J2 interface of mainboard and the power

- line 2pin for the screen as well as the power ground wire;
2. Back out both the three bolts ⑤ and the bolt ⑥ on the power board separately using TORX driver T10 and T20;
  3. Backout the two bolts and nuts ⑦ for linking up the power board and shell using a TORX driver (T10) and remove the power board;
  4. Pull out the line 12pin power to fan from the J5 interface of mainboard (locates under the fan), and then backout the four bolts ⑧ using a TORX driver (T10) to remove the fan.

## Disassemble and Assemble the Panel




Figure 5-5 Disassemble and assemble the panel

### Parts Explanations:

- ⑨ Small knobs: 4
- ⑩ Big knobs: 2
- ⑪ Bolts for fixing board on the tank body (M3\*8 Pan head Torx recess Drilling tapping screws): 5

### Disassemble steps:

1. Pull out the four small knobs ⑨ and two big knobs ⑩ (note do not damage the board by something hard)
2. Backout the five bolts from the tank body using a TORX driver (T10) to remove the board.

## Disassemble and Assemble LCD and the Keyboard




Figure 5-6 Disassemble and assemble LCD and the keyboard

### Parts Explanations:

- ⑫ Bolts for the screen ground wire (M2\*4 Pan head Torx recess machine screws): 1
- ⑬ Bolts fixed on the keypad board (M3\*6 Flush head Torx recess machine screws): 4

### Disassemble steps:

1. Pull out the LCD wire from the J603 interface of the mainboard;
2. Backout the one bolt of the screen ground wire using a TORX driver (T6);
3. Take out the LCD screen gently (Be careful the screen cable and ground wire);
4. Backout the keypad board cable from the J604 interface of the mainboard;
5. Backout the four bolts ⑬ from the keypad board using a TORX driver (T10); the moment of force is 6 NM;
6. Take out the keypad board gently (pay attention to the wire).

## Disassemble and Assemble the Mainboard




Figure 5-7 Disassemble and assemble the mainboard

### Parts Explanations:

- ⑭ Bolts on the LA board ((M3\*6 Pan head Torx recess composite machine screws): 2
- ⑮ Bolts on the cooling plate (M3\*6 Pan head Torx recess composite machine screws): 3
- ⑯ Bolts for fixing the mainboard (M3\*6 Pan head Torx recess composite machine screws): 2
- ⑰ Stud on the mainboard (M3\*6 Copper pillar): 3
- ⑱ Nuts at BNC terminal (BNC nuts): 3
- ⑲ Spacer at BNC fracture (BNC lock spacer): 3

⑳ Bolts at LA terminal (0.1\*0.3inch Hexagon Bolt in British system): 2

**Disassemble steps:**

1. Backout the two bolts ⑭ from LA board using a TORX driver (T10);
2. Backout the three bolts ⑮ from the cooling plate using a TORX driver (T10);
3. Backout the two mainboard bolts ⑯ using a TORX driver (T10), and backout the three mainboard studs ⑰ using sleeve (D89); (Pay attention that one M3 spacer is existed between LA board and stud whose position is next to the L808.)
4. Backout the three bolts ⑱ using sleeve, and remove the three spacers ⑲;
5. Backout the two bolts ⑳ at LA terminal using a TORX (T10);
6. Disconnect the earth card on the metal shell from the shore at the USB interface of the mainboard using an electric iron. (Note: please set the temperature of iron as 310℃)
7. Take out the mainboard gently after check.



## Chapter 6 Troubleshooting

### 1. After the oscilloscope is powered on, the screen remains dark (no display):

- (1) Check the power cable connection.
- (2) Ensure the power switch has been turned on.
- (3) After above inspection, restart the oscilloscope.
- (4) If the problem still remains, please ask **RIGOL** for help.

### 2. After the signal acquisition the waveform does not appear:

- (1) Check if the probe is connecting with the signals.
- (2) Check if the probe is connecting to the channels firmly.
- (3) Check if the probe is connecting with the object being tested.
- (4) Check if any signal generated from testing point.
- (5) Repeat the acquisition.

### 3. The measurement result is 10 times higher or lower than the value expected.

Check if the probe attenuation corresponds with the channel attenuation.

### 4. If the oscilloscope does not get a stable waveform display:

- (1) Check the **Source** and notice if it is set to the channel in use.
- (2) Check the **Mode**. Use **Edge** for normal signals, and use **Video** for VIDEO signals.
- (3) Switch the **Coupling** into **HF Rejection** or **LF Rejection** in order to filter the noise which disturbs trigger.
- (4) Adjust the trigger **Sensitivity** and the **Holdoff** time.

### 5. After pressing **RUN/STOP**, the oscilloscope does not display any waveform on screen.

Check whether the **Sweep** is set to **Normal** or **Single** and see whether the trigger level is out of the signal range. If it is, set the trigger level in proper range by turning the **LEVEL** knob or pressing the **50%** button. Or set the **Mode** as **AUTO**. Moreover, push **AUTO** button to display the waveform on screen.

### 6. After the Acquisition was set to "Averages" or Display Persistence is set ON, the waveform refreshes slowly.

Normal phenomenon.

### 7. The waveform is displayed on the appearance of ladder.

- (1) Normal phenomenon. Maybe the time base setting maybe is too slow. Please

rotate the horizontal SCALE knob to increase horizontal resolution to improve the display.

- (2) Maybe the display **Type** is set to **Vectors** set it to **Dots** mode to improve the display.

## Chapter 7 Replaceable Parts

**RIGOL** provides some replaceable parts in order to maintain or update for users. Please see as the following figure and table. Note that the numbers in the figure and the table are associated with each other.




Figure 7-1 DS1000E, DS1000D Exploded View

Table 7-1 Replaceable parts list

No.	Name	Specification
1	Big Knob	
2	Small Knob	
3	Panel	

4	LCD	Color Screen: FG050600ANNNA-01
5	Metallic Tank Body	
6	Rubber Button	
7	BNC Nut	BNC Nut
8	BNC Lock Spacer	BNC Lock Spacer
9	Encoder	
10	Keyboard	
11	Bolt	0.1*0.3inch Hexagon Bolt, British system
12	Fan	AFB0612LC-714
13	Large Terminal	
14	Small Terminal	
15	BNC	
16	Cooling Plate	Aluminum
17	LA Board	
18	LA Interface	
19	RS-232 Interface	
20	Power Jacket	
21	USB Host Interface	
22	Mainboard	RDSB1003
23	USB Device Interface	
24	Power Switch Cap	
25	Upper Metallic Cover	
26	Power Interface	
27	Power Supply	
28	Power Board	RDSB1001
29	Rear Metallic Cover	
30	Female ScrewLock	M3*7/ DB9 bolt, British system
31	Front Trestle	
32	Rear Trestle	
33	Handle	
34	Cover	

## **Chapter 8 Service & Support**

This chapter contains the following topics:

- Warranty
- Care and Cleaning
- Contact Us

## Warranty

**RIGOL** warrants that its products mainframe and accessories will be free from defects in materials and workmanship within the warranty period. If a product proves defective within the respective period, **RIGOL** guarantees the free replacement or repair of products which are approved defective.

To get repair service or obtain a copy of the whole warranty statement, please contact with your nearest **RIGOL** sales and service office.

**RIGOL** does not provide any other warranty items except the one being provided by this summary and the warranty statement. The warranty items include but not being subjected to the hint guarantee items related to tradable characteristic and any particular purpose.

**RIGOL** will not take any responsibility in cases regarding to indirect, particular and ensuing damage.

## Care and Cleaning

### General Maintenance

Do not store or leave the instrument in where the instrument will be exposed to direct sunlight for long periods of time.

### Caution

To avoid damages to the instrument or probes, do not expose them to liquids which have causticity.

### Cleaning

Clean the instrument and probes often based on its operating conditions require. To clean the exterior surface, perform the following steps:

1. Disconnect the instrument from all power sources.
2. Clean the loose dust on the outside of the instrument and probes with a lint-free cloth (with a mild detergent and water). When clean the LCD, take care to avoid scarifying it.



### **WARNING**

To avoid injury resulting from short circuit, make sure the instrument is completely dry before reconnecting into a power source.

---

## Contact Us

If you have any problem or requirement during using our products, please contact **RIGOL** Technologies, Inc. or the local distributors.

Domestic: Please call  
Tel: (86-10) 8070 6688  
Fax: (86-10) 8070 5070

**Service & Support Hotline: 800 810 0002**

9:00 am –5: 00 pm from Monday to Friday

Or by e-mail:  
**service@rigol.com**

Or mail to:  
**RIGOL** Technologies, Inc.  
156# CaiHe Village, ShaHe Town, ChangPing District, Beijing, China  
Post Code: 102206

Overseas: Contact the local **RIGOL** distributors or sales office.  
For the latest product information and service, visit our website: [www.rigolna.com](http://www.rigolna.com)

# Index

Acquisition.....	1-2	Mainboard .....	5-10, 7-2
Big Knob .....	7-1	Measurements .....	1-4
BNC .....	7-2	Mechanical.....	1-5
BNC Lock Spacer.....	7-2	Metallic Case.....	7-2
BNC Nut.....	7-2	Metallic Rear Cover.....	7-2
Bolt.....	7-2	P/F Interface.....	3-1, 3-8
Calibration.....	4-1	Panel.....	5-8, 7-1
Calibration Interval.....	1-5	Performance Test .....	3-1
Care and Cleaning.....	8-3	Power.....	1-5
Cleaning.....	8-3	Power Board .....	7-2
Connect the Probes.....	2-4	Power Board and the Fan.....	5-6
Contact Us .....	8-4	Power interface.....	7-2
Cooling Plate .....	7-2	Power Jacket .....	7-2
Cover .....	5-4, 7-2	Power Supply.....	7-2
Digital Probes .....	2-1, 2-7	Power-On Inspection .....	2-3
Disassembly and Assembly .....	5-1	Prepare for Use.....	2-1
Display.....	1-5	Probe Compensator .....	1-5
Display a Waveform Automatically .	2-9	Probes Compensation .....	2-5
Encoder .....	7-2	Rear trestle.....	7-2
Environmental .....	1-5	Replaceable Parts .....	7-1
Exploded View .....	7-1	RS-232 Interface .....	3-1, 3-6
Fan.....	7-2	Rubber Button .....	7-2
Front trestle .....	7-2	Small Knob .....	7-1
General Inspection .....	2-2	Small Terminal .....	7-2
General Specifications .....	1-5	Specifications.....	1-1
Handle .....	7-2	Specifications Test.....	3-11
Horizontal.....	1-2	Structure Chart .....	5-3
Inputs.....	1-2	Trigger .....	1-3
IP Degree.....	1-5	Troubleshooting .....	6-1
Keyboard.....	7-2	Upper and Rear Covers.....	5-5
LA board .....	7-2	Upper Metallic Cover.....	7-2
LA interface.....	7-2	USB Device Interface.....	3-1, 3-4
Large Terminal .....	7-2	USB Host Interface.....	3-1, 3-2
LCD .....	7-2	Vertical.....	1-2
LCD and the Keyboard.....	5-9	Warranty .....	8-2
Logic Analyzer Interface .....	3-1, 3-9		