

How to update DP800 Seires Power Supply

DP800(Software)Update(Normal).rar update file will update main program and save new analog board program to RAM ,the update file can't download the update program to analog board automatically .Need customer download analog board program manually .

If don't update analog board ,in Test/cal menu you will see analog board cal failed .

How to download analog board program ?

1. update main program ,power on DP800 when see RIGOL icon appear ,press help button you will see a note that "insert USB flash to DP800",insert the USB with .GEL update file to DP800
2. after update main program ,move USB flash ,press "help" button twice and press M4-M2-M1 button ,note need press these buttons fast ,to update analog board 1 and then press M4-M2-M2 to update analog board 2 .
3. after finish analog updating ,reboot DP800 ,in Utility menu –system info –M1-M3-M2 to check more info about version .

